



36" TRAMPOLINE WITH HANDRAIL



User Manual


**Read this entire manual before using the product.
For assistance, please contact Radio Road at
www.radioroadtoys.com**

DO NOT RETURN TO STORE

**Ages 6+
Max Weight: 165 lbs. (75 kg.)**

We make every effort to present the most current specifications and product features when printing this manual. As a result of our continual improvement, changes may be made to equipment, specifications and features without notice.

TRAMPOLINE PARTS



| Contains (1) 36" Round Trampoline Product Dimensions | |
|---|-----------------------------|
| 36.3" L x 36.3" W x 29.5" H | 92.2cm x 92.2cm x 74.9cm |
| 16 lbs. | 7.3 kg. |

SAFETY

WARNING

Be sure to read and follow the assembly instructions before assembling and using the product.

1. This trampoline is intended for users ages 6+.
2. Max 165 lbs. (75 kg.)
3. Only for indoor use.
4. The trampoline shall be assembled by an adult in accordance with the assembly instructions and thereafter checked before the first use.
5. Only one user. Collision hazard.
6. Jump with shoes.
7. Do not use the mat when it is wet.
8. Empty pockets and hands before jumping.
9. Always jump in the middle of the mat.
10. Do not eat while jumping.
11. Do not exit by a jump.
12. Limit the time of continuous usage and make regular stops.

REPLACEABLE PARTS

| PART# | DESCRIPTION | QUANTITY |
|--------------|------------------|----------|
| SP-FP-TM003 | Rubber Footpad | 8 |
| SP-SKT-TM003 | Trampoline Skirt | 1 |
| SP-MAT-TM003 | Trampoline Mat | 1 |
| SP-SPR-TM003 | Springs | 30 |
| SP-LHR-TM003 | Long Handrail | 2 |
| SP-CHR-TM003 | Center Handrail | 1 |
| SP-FK-TM003 | Fastening Knob | 2 |
| SP-FL-TM003t | Frame Leg | 6 |

ASSEMBLY INSTRUCTIONS

1. Remove the plastic caps from the bottom of the trampoline frame; these will reveal threaded posts.




2. Locate the six (6) Frame Legs and attach them to the trampoline frame by screwing them onto the revealed posts.



3. Find the Right Handrail section. Lift or tilt the trampoline frame and slide the collar attached to the Right Handrail over a Frame Leg then rotate inward toward the center of the trampoline mat. You will need to remove the Rubber Footpad to do so.



4. Repeat step 3 with the Left Handrail and rotate both to face one another. See the diagram below for reference.



5. Locate the Center Handrail section. With the bent portion facing away from the trampoline, slide the left side of the Center Handrail over the exposed end of the Left Handrail section and repeat with the right side. Push or roll the foam back on the Center Handrail ends to ensure that both spring buttons are engaged and pop through the stamped holes in the ends of the Left and Right Handrails.



6. Put the Rubber Footpads back on and lay the trampoline on its feet. Make sure that the handrail legs and the Frame Legs are all touching the ground then tighten the Fastening Knobs until the handrail is secure on both sides.



7. Check that all parts are properly fastened and secured before using.

MAINTENANCE

Keep this manual for future reference of assembly and product care. For general safety and maintenance, prior to each use the product should always be inspected for damaged or defective parts including:

- checking all nuts and bolts for tightness and tightened as needed
- checking that all spring-loaded joints are still intact and cannot become dislodged during play
- checking all coverings and sharp edges to be replaced when required
- checking that the mat, skirt/padding, and handle are without defects

USING THE TRAMPOLINE

Your trampoline is intended for indoor use only. It should not be used outdoors and is not intended to be buried in the ground or used without the included Frame Legs.

We strongly recommend that:

- the trampoline is always used on a level surface
- the trampoline is at least 6 ft. (2m) from any structure or obstruction such as furniture, walls, tables, lamps, etc.
- the trampoline is not installed over concrete, asphalt, or any other hard surfaces nor within proximity of other play structures
- when moving the trampoline, pick up and carry by the frame and not the handrail

For maximum safety and fun, follow the tips below!

1. Always step onto and off of the trampoline from the side opposite the handrail.
2. When jumping, stay in the center of the mat and jump straight up and down.
3. The handrail should always be used when jumping for added balance. It should not be pulled on, hung on, or used for any stunts or maneuvers.
4. Never jump onto the trampoline from any other surface higher than the ground.

WARRANTY



DO NOT RETURN TO STORE

Failure to follow these instructions may damage your product and void your warranty.



Radio Road Limited Warranty:

Radio Road warrants that this product shall be free from defects in workmanship for one year from the day of purchase. If the product is defective, Radio Road's sole obligation under this warranty shall be at its election, subject to the terms of this warranty, to repair or replace any parts deemed defective. This warranty is for the exclusive benefit of the original purchaser and is not assignable or transferable. THIS WARRANTY IS MADE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, AND ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE TERMS OF THIS WARRANTY, UNLESS OTHERWISE PROHIBITED BY LAW.

Exclusions

To the fullest extent permitted by law, Radio Road expressly disclaims and excludes from this warranty any liability for damages, including but not limited to general, special, indirect, incidental, consequential, aggravated, punitive or exemplary damages, and economic loss (even if Radio Road is informed of their possibility), third party claims against you, including for any loss or damages, and claims or damages related to loss of, or, damage to, your records or data. This warranty does not apply to any product the exterior of which has been damaged or defaced. This warranty will be voided by misuse, improper physical environment, improper repair, acts of God, war or terror, commercial use, and improper service, operation or handling.

Return Merchandise for Service

Any claim under this warranty must be made in writing to Radio Road, at the address provided by our technician, within 30 days after the owner discovers the circumstances giving rise to any such claim, and must include a copy of this warranty document, a receipt or copy of your invoice marked with the date of purchase and the original packaging. You may obtain service by calling the technician for a Return Merchandise Authorization (RMA) number. The RMA number must be prominently displayed on the outside of the shipping carton and the package must be mailed to Radio Road postage prepaid.

Radio Road
4720 Radio Road
Naples, Florida 34104
877-818-4221
www.radioroadtoys.com